PROMESS GANTRY

The Gantry gives the Promess Work Station ability to position the EMAP anywhere within the Work Station's envelope.

Promess Work Stations equipped with the Gantry Frame are free of the limitations of a rigid, stationary press. The Gantry accessory accurately positions the attached press unit anywhere within the workstation's work envelope. Moving on both X and Y axes, the Gantry accessory allows programmed or manually controlled movement from part to part to fit the needs of specific applications.





Get more process flexibility with a full range of movement across both axes

FEATURES AND BENEFITS

- Load bearing design matches with Promess EMAP presses
- Distributed intelligence allows for easy seamless integrations
- Simple X/Y positioning capabilities



Scan here to view a video of the Gantry accessory on a Promess Work Station.

